

# DIODE DYNAMICS

PERFORMANCE LIGHTING TECHNOLOGY

## 2015+ Ford Mustang Sidemarker Installation Guide



Thank you for your purchase of this unique product for your Ford Mustang! With this plug-and-play LED Sidemarker, you will be able to upgrade your factory sidemarker to a brighter, more modern appearance on the road. This product is a direct replacement for your factory sidemarker.



1. Remove the factory sidemarker by reaching behind and depressing the tab on the side closest to the wheel well. Once the tab is unclipped, slide the sidemarker towards the wheel well to pull the sidemarker housing out.



2. Looking at the factory sidemarker housing, rotate the socket clockwise and pull the socket out. Set the factory sidemarker aside. It will not be reused.

*See back for further instructions.*



## 2015+ Ford Mustang Sidemarker Installation Guide



3. Allow the factory bulb to cool and remove the factory bulb. Insert the connector on your LED sidemarker in its place.



4. Reinstall the socket back into your new sidemarker housing by turning the socket counter-clockwise to lock it into place.



5. Finish your installation by sliding and clipping your new LED sidemarker into place

### **NEED MORE HELP?**

Scan the QR code to link to our installation video online!

We've taken the time to test our products on your vehicle. We can guarantee compatibility and fitment the first time - no guessing game! If you need more help with installation, watch our step-by-step video to walk you through the process.

YouTube



Please contact **Diode Dynamics** should you have any questions about the installation or wiring process, at **314-205-3033** (9a-5p CST) or **contact@diodedynamics.com**.

Visit [www.diodedynamics.com](http://www.diodedynamics.com) to find more products for any vehicle.

**100% SATISFACTION  
GUARANTEE**

**3 YEAR  
WARRANTY**

