

Year	Make	Model	EngineLiters	EngineCID
1955	Mercury	Custom	4.8	292
1955	Mercury	Montclair	4.8	292
1955	Mercury	Monterey	4.8	292
1957	Ford	Courier Sedan Delivery	5.8	352
1957	Ford	Custom	4.8	292
1957	Ford	Custom 300	4.8	292
1957	Ford	Del Rio Wagon	4.8	292
1957	Ford	F Series	5.8	352
1957	Ford	Ranchero	5.8	352
1958	Ford	Club	5.8	352
1958	Ford	Country Sedan	4.8	292
1958	Ford	Country Sedan	5.4	332
1958	Ford	Country Sedan	5.8	352
1958	Ford	Country Squire	4.8	292
1958	Ford	Country Squire	5.4	332
1958	Ford	Country Squire	5.8	352
1958	Ford	Courier Sedan Delivery	5.8	352
1958	Ford	Custom 300	4.8	292
1958	Ford	Custom 300	5.4	332
1958	Ford	Custom 300	5.8	352
1958	Ford	Del Rio Wagon	4.8	292
1958	Ford	Del Rio Wagon	5.4	332
1958	Ford	Del Rio Wagon	5.8	352
1958	Ford	F Series	5.8	352
1958	Ford	Fairlane	5.8	352
1958	Ford	Ranch Wagon	5.8	352
1958	Ford	Ranchero	5.8	352
1958	Ford	Skyliner	5.8	352
1958	Ford	Sunliner	5.8	352
1958	Ford	Thunderbird	5.8	352
1958	Ford	Victoria	5.8	352
1958	Mercury	Colony Park	7.0	430
1958	Mercury	Montclair	7.0	430
1958	Mercury	Park Lane	7.0	430
1958	Mercury	Voyager	7.0	430
1959	Edsel	Corsair	5.4	332
1959	Edsel	Ranger	4.8	292
1959	Edsel	Villager	4.8	292
1959	Ford	Club	4.8	292
1959	Ford	Club	5.8	352
1959	Ford	Country Sedan	4.8	292
1959	Ford	Country Sedan	5.4	332
1959	Ford	Country Sedan	5.8	352
1959	Ford	Country Squire	4.8	292
1959	Ford	Country Squire	5.4	332
1959	Ford	Country Squire	5.8	352

1959	Ford	Custom 300	4.8	292
1959	Ford	Custom 300	5.4	332
1959	Ford	Custom 300	5.8	352
1959	Ford	F Series	4.8	292
1959	Ford	F Series	5.8	352
1959	Ford	Fairlane	4.8	292
1959	Ford	Fairlane	5.4	332
1959	Ford	Fairlane	5.8	352
1959	Ford	Galaxie	4.8	292
1959	Ford	Galaxie	5.4	332
1959	Ford	Galaxie	5.8	352
1959	Ford	Ranch Wagon	4.8	292
1959	Ford	Ranch Wagon	5.4	332
1959	Ford	Ranch Wagon	5.8	352
1959	Ford	Ranchero	5.8	352
1959	Ford	Skyliner	4.8	292
1959	Ford	Skyliner	5.4	332
1959	Ford	Skyliner	5.8	352
1959	Ford	Sunliner	4.8	292
1959	Ford	Sunliner	5.4	332
1959	Ford	Sunliner	5.8	352
1959	Ford	Thunderbird	5.4	332
1959	Ford	Thunderbird	5.8	352
1959	Ford	Thunderbird	7.0	430
1959	Ford	Victoria	4.8	292
1959	Ford	Victoria	5.4	332
1959	Ford	Victoria	5.8	352
1959	Mercury	Colony Park	7.0	430
1959	Mercury	Commuter	7.0	430
1959	Mercury	Country Cruiser	7.0	430
1959	Mercury	Montclair	7.0	430
1959	Mercury	Monterey	7.0	430
1959	Mercury	Park Lane	7.0	430
1959	Mercury	Voyager	7.0	430
1960	American Motors	Ambassador	5.4	327
1960	American Motors	Rebel	4.1	250
1960	Edsel	Ranger	4.8	292
1960	Edsel	Villager	4.8	292
1960	Ford	Country Sedan	4.8	292
1960	Ford	Country Sedan	5.8	352
1960	Ford	Country Squire	4.8	292
1960	Ford	Country Squire	5.8	352
1960	Ford	Custom 300	5.8	352
1960	Ford	F-100	4.8	292
1960	Ford	F-250	4.8	292
1960	Ford	F-350	4.8	292
1960	Ford	Fairlane	4.8	292

1960	Ford	Fairlane	5.8	352
1960	Ford	Galaxie	4.8	292
1960	Ford	Galaxie	5.8	352
1960	Ford	Ranch Wagon	4.8	292
1960	Ford	Ranch Wagon	5.8	352
1960	Ford	Starliner	4.8	292
1960	Ford	Starliner	5.8	352
1960	Ford	Sunliner	4.8	292
1960	Ford	Sunliner	5.8	352
1960	Ford	Thunderbird	5.8	352
1960	Ford	Thunderbird	7.0	430
1960	Ford	Victoria	4.8	292
1960	Ford	Victoria	5.8	352
1960	Lincoln	Continental	7.0	430
1960	Lincoln	Lincoln Series	7.0	430
1960	Lincoln	Premier	7.0	430
1960	Mercury	Colony Park	7.0	430
1960	Mercury	Park Lane	7.0	430
1961	American Motors	Ambassador	5.4	327
1961	American Motors	Rebel	4.1	250
1961	Ford	Country Sedan	4.8	292
1961	Ford	Country Sedan	5.8	352
1961	Ford	Country Squire	4.8	292
1961	Ford	Country Squire	5.8	352
1961	Ford	F-100	4.8	292
1961	Ford	F-250	4.8	292
1961	Ford	F-350	4.8	292
1961	Ford	Fairlane	4.8	292
1961	Ford	Fairlane	5.8	352
1961	Ford	Fairlane	6.4	390
1961	Ford	Galaxie	4.8	292
1961	Ford	Galaxie	5.8	352
1961	Ford	Galaxie	6.4	390
1961	Ford	Ranch Wagon	4.8	292
1961	Ford	Ranch Wagon	5.8	352
1961	Ford	Ranch Wagon	6.4	390
1961	Ford	Thunderbird	6.4	390
1961	Lincoln	Continental	7.0	430
1961	Mercury	Colony Park	4.8	292
1961	Mercury	Colony Park	5.8	352
1961	Mercury	Commuter	4.8	292
1961	Mercury	Commuter	5.8	352
1961	Mercury	Commuter	6.4	390
1961	Mercury	Meteor	4.8	292
1961	Mercury	Meteor	5.8	352
1961	Mercury	Meteor	6.4	390
1961	Mercury	Monterey	4.8	292

1961	Mercury	Monterey	5.8	352
1962	American Motors	Ambassador	5.4	327
1962	Ford	Country Sedan	4.8	292
1962	Ford	Country Sedan	5.8	352
1962	Ford	Country Sedan	6.4	390
1962	Ford	Country Squire	4.8	292
1962	Ford	Country Squire	5.8	352
1962	Ford	Country Squire	6.4	390
1962	Ford	F-100	4.8	292
1962	Ford	F-250	4.8	292
1962	Ford	F-350	4.8	292
1962	Ford	Fairlane	3.6	221
1962	Ford	Fairlane	3.6	223
1962	Ford	Fairlane	4.3	260
1962	Ford	Fairlane	4.8	292
1962	Ford	Fairlane	5.8	352
1962	Ford	Fairlane	6.4	390
1962	Ford	Galaxie	4.8	292
1962	Ford	Galaxie	5.8	352
1962	Ford	Galaxie	6.4	390
1962	Ford	Galaxie 500	4.8	292
1962	Ford	Galaxie 500	5.8	352
1962	Ford	Galaxie 500	6.4	390
1962	Ford	Galaxie 500	6.7	406
1962	Ford	Ranch Wagon	4.8	292
1962	Ford	Ranch Wagon	5.8	352
1962	Ford	Ranch Wagon	6.4	390
1962	Ford	Sunliner	4.8	292
1962	Ford	Sunliner	5.8	352
1962	Ford	Sunliner	6.4	390
1962	Ford	Thunderbird	6.4	390
1962	Ford	Thunderbird	6.7	410
1962	Ford	Victoria	4.8	292
1962	Ford	Victoria	5.8	352
1962	Ford	Victoria	6.4	390
1962	Mercury	Colony Park	4.8	292
1962	Mercury	Colony Park	5.8	352
1962	Mercury	Colony Park	6.4	390
1962	Mercury	Commuter	6.4	390
1962	Mercury	Meteor	3.6	221
1962	Mercury	Monterey	4.8	292
1962	Mercury	Monterey	5.8	352
1962	Mercury	Monterey	6.4	390
1963	American Motors	Ambassador	5.4	327
1963	American Motors	Classic	4.7	287
1963	Ford	Country Sedan	4.3	260
1963	Ford	Country Sedan	4.7	289

1963	Ford	Country Sedan	5.8	352
1963	Ford	Country Sedan	6.4	390
1963	Ford	Country Squire	4.3	260
1963	Ford	Country Squire	4.7	289
1963	Ford	Country Squire	5.8	352
1963	Ford	Country Squire	6.4	390
1963	Ford	F-100	4.8	292
1963	Ford	F-250	4.8	292
1963	Ford	F-350	4.8	292
1963	Ford	Fairlane	3.6	221
1963	Ford	Fairlane	4.3	260
1963	Ford	Fairlane	4.7	289
1963	Ford	Fairlane	5.8	352
1963	Ford	Fairlane	6.4	390
1963	Ford	Falcon	4.3	260
1963	Ford	Falcon Sedan Delivery	4.3	260
1963	Ford	Ford 300	4.3	260
1963	Ford	Ford 300	4.7	289
1963	Ford	Ford 300	5.8	352
1963	Ford	Galaxie	4.3	260
1963	Ford	Galaxie	4.7	289
1963	Ford	Galaxie	5.8	352
1963	Ford	Galaxie	6.4	390
1963	Ford	Galaxie 500	4.3	260
1963	Ford	Galaxie 500	4.7	289
1963	Ford	Galaxie 500	5.8	352
1963	Ford	Galaxie 500	6.4	390
1963	Ford	Galaxie 500	6.7	406
1963	Ford	Ranch Wagon	4.3	260
1963	Ford	Ranch Wagon	4.7	289
1963	Ford	Ranch Wagon	5.8	352
1963	Ford	Ranch Wagon	6.4	390
1963	Ford	Ranchero	4.3	260
1963	Ford	Sprint	3.6	221
1963	Ford	Sprint	4.3	260
1963	Ford	Sunliner	4.7	289
1963	Ford	Sunliner	5.8	352
1963	Ford	Sunliner	6.4	390
1963	Ford	Thunderbird	6.4	390
1963	Ford	Thunderbird	6.7	410
1963	Ford	Thunderbird	7.0	427
1963	Ford	Victoria	4.3	260
1963	Ford	Victoria	4.7	289
1963	Ford	Victoria	5.8	352
1963	Mercury	Colony Park	6.4	390
1963	Mercury	Comet	4.3	260
1963	Mercury	Country Cruiser	3.6	221

1963	Mercury	Marauder	6.4	390
1963	Mercury	Meteor	3.6	221
1963	Mercury	Monterey	6.4	390
1963	Mercury	Villager	4.3	260
1964	American Motors	Classic	4.7	287
1964	Ford	Country Sedan	4.3	260
1964	Ford	Country Sedan	4.7	289
1964	Ford	Country Sedan	5.8	352
1964	Ford	Country Sedan	6.4	390
1964	Ford	Country Sedan	7.0	427
1964	Ford	Country Squire	4.3	260
1964	Ford	Country Squire	4.7	289
1964	Ford	Country Squire	5.8	352
1964	Ford	Country Squire	6.4	390
1964	Ford	Country Squire	7.0	427
1964	Ford	Custom	4.3	260
1964	Ford	Custom	5.8	352
1964	Ford	Custom	6.4	390
1964	Ford	Custom 500	4.3	260
1964	Ford	Custom 500	4.7	289
1964	Ford	Custom 500	5.8	352
1964	Ford	Custom 500	6.4	390
1964	Ford	F-100	4.8	292
1964	Ford	F-250	4.8	292
1964	Ford	F-350	4.8	292
1964	Ford	F-350	5.9	361
1964	Ford	F-350	5.9	360
1964	Ford	Fairlane	4.3	260
1964	Ford	Fairlane	4.7	289
1964	Ford	Fairlane	5.8	352
1964	Ford	Fairlane	6.4	390
1964	Ford	Fairlane	7.0	427
1964	Ford	Falcon	4.3	260
1964	Ford	Falcon	4.7	289
1964	Ford	Falcon Sedan Delivery	4.3	260
1964	Ford	Galaxie	4.3	260
1964	Ford	Galaxie	4.7	289
1964	Ford	Galaxie	5.8	352
1964	Ford	Galaxie	6.4	390
1964	Ford	Galaxie 500	4.3	260
1964	Ford	Galaxie 500	4.7	289
1964	Ford	Galaxie 500	5.8	352
1964	Ford	Galaxie 500	6.4	390
1964	Ford	Mustang	4.3	260
1964	Ford	Mustang	4.7	289
1964	Ford	Ranch Wagon	4.3	260
1964	Ford	Ranch Wagon	4.7	289

1964	Ford	Ranch Wagon	5.8	352
1964	Ford	Ranch Wagon	6.4	390
1964	Ford	Ranch Wagon	7.0	427
1964	Ford	Ranchero	4.3	260
1964	Ford	Sprint	4.3	260
1964	Ford	Sunliner	4.3	260
1964	Ford	Sunliner	5.8	352
1964	Ford	Sunliner	6.4	390
1964	Ford	Thunderbird	6.4	390
1964	Ford	Thunderbird	7.0	427
1964	Ford	Victoria	4.3	260
1964	Ford	Victoria	5.8	352
1964	Ford	Victoria	6.4	390
1964	International	C1100	5.0	304
1964	International	C1200	5.0	304
1964	Mercury	Caliente	4.3	260
1964	Mercury	Caliente	4.7	289
1964	Mercury	Colony Park	6.4	390
1964	Mercury	Comet	4.3	260
1964	Mercury	Comet	4.7	289
1964	Mercury	Commuter	6.4	390
1964	Mercury	Cyclone	4.3	260
1964	Mercury	Cyclone	4.7	289
1964	Mercury	Marauder	6.4	390
1964	Mercury	Montclair	6.4	390
1964	Mercury	Monterey	6.4	390
1964	Mercury	Park Lane	6.4	390
1964	Mercury	Villager	4.3	260
1964	Mercury	Villager	4.7	289
1965	American Motors	Classic	4.7	287
1965	American Motors	Marlin	4.7	287
1965	Ford	Country Sedan	4.7	289
1965	Ford	Country Sedan	5.8	352
1965	Ford	Country Sedan	6.4	390
1965	Ford	Country Sedan	7.0	427
1965	Ford	Country Squire	4.7	289
1965	Ford	Country Squire	5.8	352
1965	Ford	Custom	4.7	289
1965	Ford	Custom	5.8	352
1965	Ford	Custom	6.4	390
1965	Ford	Custom 500	4.7	289
1965	Ford	Custom 500	5.8	352
1965	Ford	Custom 500	7.0	427
1965	Ford	F-100	5.8	352
1965	Ford	F-250	5.8	352
1965	Ford	F-350	5.8	352
1965	Ford	F-350	5.9	361

1965	Ford	F-350	5.9	360
1965	Ford	Fairlane	4.7	289
1965	Ford	Fairlane	5.8	352
1965	Ford	Fairlane	6.4	390
1965	Ford	Fairlane	7.0	427
1965	Ford	Falcon	4.7	289
1965	Ford	Falcon Sedan Delivery	4.7	289
1965	Ford	Galaxie	4.7	289
1965	Ford	Galaxie	5.8	352
1965	Ford	Galaxie	6.4	390
1965	Ford	Galaxie	7.0	427
1965	Ford	Galaxie 500	4.7	289
1965	Ford	Galaxie 500	5.8	352
1965	Ford	Galaxie 500	6.4	390
1965	Ford	Galaxie 500	7.0	427
1965	Ford	LTD	4.7	289
1965	Ford	LTD	5.8	352
1965	Ford	LTD	6.4	390
1965	Ford	LTD	7.0	427
1965	Ford	LTD	7.0	428
1965	Ford	Mustang	4.7	289
1965	Ford	Ranch Wagon	4.7	289
1965	Ford	Ranch Wagon	5.8	352
1965	Ford	Ranch Wagon	6.4	390
1965	Ford	Ranch Wagon	7.0	427
1965	Ford	Ranchero	4.7	289
1965	Ford	Thunderbird	6.4	390
1965	Ford	Thunderbird	7.0	427
1965	International	D1200	5.0	304
1965	International	D300	4.4	266
1965	Mercury	Breezeway	6.4	390
1965	Mercury	Breezeway	7.0	427
1965	Mercury	Caliente	4.7	289
1965	Mercury	Caliente	7.0	427
1965	Mercury	Colony Park	6.4	390
1965	Mercury	Colony Park	7.0	427
1965	Mercury	Comet	4.7	289
1965	Mercury	Comet	7.0	427
1965	Mercury	Commuter	6.4	390
1965	Mercury	Commuter	7.0	427
1965	Mercury	Cyclone	4.7	289
1965	Mercury	Cyclone	7.0	427
1965	Mercury	Marauder	6.4	390
1965	Mercury	Marauder	7.0	427
1965	Mercury	Montclair	6.4	390
1965	Mercury	Montclair	7.0	427
1965	Mercury	Monterey	6.4	390

1965	Mercury	Monterey	7.0	427
1965	Mercury	Park Lane	6.4	390
1965	Mercury	Park Lane	7.0	427
1965	Mercury	Villager	4.7	289
1965	Mercury	Villager	7.0	427
1966	American Motors	Ambassador	4.7	287
1966	American Motors	Classic	4.7	287
1966	American Motors	Classic	4.7	290
1966	American Motors	Marlin	4.7	287
1966	Ford	Bronco	4.7	289
1966	Ford	Country Sedan	4.7	289
1966	Ford	Country Sedan	5.8	352
1966	Ford	Country Sedan	6.4	390
1966	Ford	Country Sedan	7.0	428
1966	Ford	Country Sedan	7.0	427
1966	Ford	Country Squire	4.7	289
1966	Ford	Country Squire	5.8	352
1966	Ford	Country Squire	7.0	428
1966	Ford	Country Squire	7.0	427
1966	Ford	Custom	4.7	289
1966	Ford	Custom	5.8	352
1966	Ford	Custom	6.4	390
1966	Ford	Custom	7.0	428
1966	Ford	Custom	7.0	427
1966	Ford	Custom 500	4.7	289
1966	Ford	Custom 500	5.8	352
1966	Ford	Custom 500	6.4	390
1966	Ford	Custom 500	7.0	427
1966	Ford	Custom 500	7.0	428
1966	Ford	F-100	5.8	352
1966	Ford	F-250	5.8	352
1966	Ford	F-350	5.8	352
1966	Ford	F-350	5.9	361
1966	Ford	F-350	5.9	360
1966	Ford	Fairlane	4.7	289
1966	Ford	Fairlane	5.8	352
1966	Ford	Fairlane	6.4	390
1966	Ford	Fairlane	7.0	427
1966	Ford	Falcon	4.7	289
1966	Ford	Galaxie	4.7	289
1966	Ford	Galaxie	5.8	352
1966	Ford	Galaxie	6.4	390
1966	Ford	Galaxie	7.0	428
1966	Ford	Galaxie	7.0	427
1966	Ford	Galaxie 500	4.7	289
1966	Ford	Galaxie 500	5.8	352
1966	Ford	Galaxie 500	6.4	390

1966	Ford	Galaxie 500	7.0	427
1966	Ford	GT40	4.7	289
1966	Ford	LTD	4.7	289
1966	Ford	LTD	5.8	352
1966	Ford	LTD	6.4	390
1966	Ford	LTD	7.0	428
1966	Ford	LTD	7.0	427
1966	Ford	Mustang	4.7	289
1966	Ford	Ranch Wagon	4.7	289
1966	Ford	Ranch Wagon	5.8	352
1966	Ford	Ranch Wagon	6.4	390
1966	Ford	Ranch Wagon	7.0	428
1966	Ford	Ranch Wagon	7.0	427
1966	Ford	Ranchero	4.7	289
1966	Ford	Thunderbird	6.4	390
1966	Ford	Thunderbird	7.0	428
1966	Ford	Thunderbird	7.0	427
1966	International	1100A	5.0	304
1966	International	1200A	5.0	304
1966	Mercury	Breezeway	6.4	390
1966	Mercury	Breezeway	6.7	410
1966	Mercury	Breezeway	7.0	428
1966	Mercury	Breezeway	7.0	427
1966	Mercury	Caliente	4.7	289
1966	Mercury	Caliente	6.4	390
1966	Mercury	Colony Park	6.4	390
1966	Mercury	Colony Park	6.7	410
1966	Mercury	Colony Park	7.0	428
1966	Mercury	Colony Park	7.0	427
1966	Mercury	Comet	4.7	289
1966	Mercury	Comet	6.4	390
1966	Mercury	Comet	7.0	427
1966	Mercury	Commuter	6.4	390
1966	Mercury	Commuter	6.7	410
1966	Mercury	Commuter	7.0	428
1966	Mercury	Commuter	7.0	427
1966	Mercury	Cyclone	4.7	289
1966	Mercury	Cyclone	6.4	390
1966	Mercury	Marauder	6.4	390
1966	Mercury	Montclair	6.4	390
1966	Mercury	Montclair	6.7	410
1966	Mercury	Montclair	7.0	428
1966	Mercury	Montclair	7.0	427
1966	Mercury	Monterey	6.4	390
1966	Mercury	Monterey	6.7	410
1966	Mercury	Monterey	7.0	428
1966	Mercury	Monterey	7.0	427

1966	Mercury	Park Lane	6.4	390
1966	Mercury	Park Lane	6.7	410
1966	Mercury	Park Lane	7.0	428
1966	Mercury	Park Lane	7.0	427
1966	Mercury	Villager	4.7	289
1966	Mercury	Villager	6.4	390
1966	Mercury	Voyager	4.7	289
1966	Mercury	Voyager	6.4	390
1967	American Motors	Ambassador	4.7	287
1967	American Motors	Ambassador	4.7	290
1967	Ford	Bronco	4.7	289
1967	Ford	Country Sedan	4.7	289
1967	Ford	Country Sedan	5.8	352
1967	Ford	Country Sedan	6.4	390
1967	Ford	Country Squire	4.7	289
1967	Ford	Country Squire	5.8	352
1967	Ford	Country Squire	6.4	390
1967	Ford	Country Squire	7.0	427
1967	Ford	Custom	4.7	289
1967	Ford	Custom	6.4	390
1967	Ford	Custom 500	4.7	289
1967	Ford	Custom 500	6.4	390
1967	Ford	Custom 500	7.0	427
1967	Ford	F-100	5.8	352
1967	Ford	F-250	5.8	352
1967	Ford	F-350	5.8	352
1967	Ford	Fairlane	4.7	289
1967	Ford	Fairlane	6.4	390
1967	Ford	Fairlane	7.0	427
1967	Ford	Falcon	4.7	289
1967	Ford	Galaxie	4.7	289
1967	Ford	Galaxie	6.4	390
1967	Ford	Galaxie	7.0	428
1967	Ford	Galaxie	7.0	427
1967	Ford	Galaxie 500	4.7	289
1967	Ford	Galaxie 500	6.4	390
1967	Ford	Galaxie 500	7.0	427
1967	Ford	GT40	4.7	289
1967	Ford	LTD	4.7	289
1967	Ford	LTD	6.4	390
1967	Ford	LTD	7.0	428
1967	Ford	LTD	7.0	427
1967	Ford	Mustang	4.7	289
1967	Ford	Mustang	6.4	390
1967	Ford	Ranch Wagon	4.7	289
1967	Ford	Ranch Wagon	6.4	390
1967	Ford	Ranch Wagon	7.0	428

1967	Ford	Ranch Wagon	7.0	427
1967	Ford	Ranchero	4.7	289
1967	Ford	Ranchero	6.4	390
1967	Ford	Thunderbird	6.4	390
1967	Ford	Thunderbird	7.0	428
1967	Ford	Thunderbird	7.0	427
1967	International	1000B	4.4	266
1967	International	1100B	4.4	266
1967	International	1200B	4.4	266
1967	Mercury	Brougham	7.0	428
1967	Mercury	Brougham	7.0	427
1967	Mercury	Caliente	4.7	289
1967	Mercury	Caliente	6.4	390
1967	Mercury	Colony Park	6.4	390
1967	Mercury	Colony Park	7.0	428
1967	Mercury	Colony Park	7.0	427
1967	Mercury	Comet	4.7	289
1967	Mercury	Comet	6.4	390
1967	Mercury	Comet	7.0	427
1967	Mercury	Commuter	4.7	289
1967	Mercury	Commuter	6.4	390
1967	Mercury	Commuter	7.0	428
1967	Mercury	Commuter	7.0	427
1967	Mercury	Cougar	4.7	289
1967	Mercury	Cougar	6.4	390
1967	Mercury	Cyclone	4.7	289
1967	Mercury	Cyclone	6.4	390
1967	Mercury	Marauder	6.4	390
1967	Mercury	Marquis	7.0	428
1967	Mercury	Marquis	7.0	427
1967	Mercury	Montclair	6.4	390
1967	Mercury	Montclair	7.0	428
1967	Mercury	Montclair	7.0	427
1967	Mercury	Monterey	6.4	390
1967	Mercury	Monterey	7.0	428
1967	Mercury	Monterey	7.0	427
1967	Mercury	Park Lane	7.0	428
1967	Mercury	Park Lane	7.0	427
1967	Mercury	Villager	4.7	289
1967	Mercury	Villager	6.4	390
1967	Mercury	Voyager	4.7	289
1967	Mercury	Voyager	6.4	390
1968	American Motors	Ambassador	4.8	290
1968	American Motors	Ambassador	5.6	343
1968	American Motors	Ambassador	6.4	390
1968	American Motors	AMX	4.8	290
1968	American Motors	AMX	5.6	343

1968	American Motors	AMX	6.4	390
1968	American Motors	Javelin	5.6	343
1968	American Motors	Javelin	6.4	390
1968	American Motors	Rebel	5.6	343
1968	Ford	Bronco	4.7	289
1968	Ford	Bronco	5.0	302
1968	Ford	Country Sedan	5.0	302
1968	Ford	Country Sedan	6.4	390
1968	Ford	Country Sedan	7.0	428
1968	Ford	Country Squire	5.0	302
1968	Ford	Country Squire	6.4	390
1968	Ford	Country Squire	7.0	428
1968	Ford	Country Squire	7.0	427
1968	Ford	Custom	5.0	302
1968	Ford	Custom	6.4	390
1968	Ford	Custom	7.0	428
1968	Ford	Custom 500	4.7	289
1968	Ford	Custom 500	5.0	302
1968	Ford	Custom 500	6.4	390
1968	Ford	Custom 500	7.0	427
1968	Ford	Custom 500	7.0	428
1968	Ford	E-100 Econoline	5.0	302
1968	Ford	E-200 Econoline	5.0	302
1968	Ford	E-300 Econoline	5.0	302
1968	Ford	F-100	5.9	360
1968	Ford	F-100	6.4	390
1968	Ford	F-250	5.9	360
1968	Ford	F-250	6.4	390
1968	Ford	F-350	5.9	360
1968	Ford	F-350	6.4	390
1968	Ford	Fairlane	4.7	289
1968	Ford	Fairlane	5.0	302
1968	Ford	Fairlane	6.4	390
1968	Ford	Fairlane	7.0	428
1968	Ford	Fairlane	7.0	427
1968	Ford	Falcon	4.7	289
1968	Ford	Falcon	5.0	302
1968	Ford	Galaxie 500	5.0	302
1968	Ford	Galaxie 500	6.4	390
1968	Ford	Galaxie 500	7.0	428
1968	Ford	Galaxie 500	7.0	427
1968	Ford	GT40	4.7	289
1968	Ford	LTD	4.7	289
1968	Ford	LTD	5.0	302
1968	Ford	LTD	6.4	390
1968	Ford	LTD	7.0	428
1968	Ford	LTD	7.0	427

1968 Ford	Mustang	4.7	289
1968 Ford	Mustang	5.0	302
1968 Ford	Mustang	6.4	390
1968 Ford	Mustang	7.0	428
1968 Ford	Mustang	7.0	427
1968 Ford	Ranch Wagon	4.7	289
1968 Ford	Ranch Wagon	5.0	302
1968 Ford	Ranch Wagon	6.4	390
1968 Ford	Ranch Wagon	7.0	428
1968 Ford	Ranchero	5.0	302
1968 Ford	Ranchero	6.4	390
1968 Ford	Ranchero	7.0	428
1968 Ford	Thunderbird	6.4	390
1968 Ford	Thunderbird	7.0	429
1968 Ford	Torino	4.7	289
1968 Ford	Torino	5.0	302
1968 Ford	Torino	6.4	390
1968 Ford	Torino	7.0	428
1968 Ford	Torino	7.0	427
1968 International	1000C	4.4	266
1968 International	1100C	4.4	266
1968 International	1200C	4.4	266
1968 International	1300C	4.4	266
1968 International	908C	4.4	266
1968 International	M1200	4.4	266
1968 International	MA1200	4.4	266
1968 International	Scout	4.4	266
1968 Mercury	Colony Park	6.4	390
1968 Mercury	Colony Park	7.0	428
1968 Mercury	Comet	5.0	302
1968 Mercury	Comet	6.4	390
1968 Mercury	Commuter	6.4	390
1968 Mercury	Commuter	7.0	428
1968 Mercury	Cougar	4.7	289
1968 Mercury	Cougar	5.0	302
1968 Mercury	Cougar	6.4	390
1968 Mercury	Cougar	7.0	428
1968 Mercury	Cougar	7.0	427
1968 Mercury	Cyclone	5.0	302
1968 Mercury	Cyclone	6.4	390
1968 Mercury	Cyclone	7.0	428
1968 Mercury	Cyclone	7.0	427
1968 Mercury	Marquis	6.4	390
1968 Mercury	Marquis	7.0	428
1968 Mercury	Montclair	6.4	390
1968 Mercury	Montclair	7.0	428
1968 Mercury	Montego	5.0	302

1968	Mercury	Montego	6.4	390
1968	Mercury	Montego	7.0	428
1968	Mercury	Montego	7.0	427
1968	Mercury	Monterey	6.4	390
1968	Mercury	Monterey	7.0	428
1968	Mercury	Park Lane	6.4	390
1968	Mercury	Park Lane	7.0	428
1969	American Motors	Ambassador	4.8	290
1969	American Motors	Ambassador	5.1	309
1969	American Motors	Ambassador	5.6	343
1969	American Motors	Ambassador	6.4	390
1969	American Motors	AMX	4.8	290
1969	American Motors	AMX	5.6	343
1969	American Motors	AMX	6.4	390
1969	American Motors	Javelin	5.6	343
1969	American Motors	Javelin	6.4	390
1969	American Motors	Rambler	6.4	390
1969	American Motors	Rebel	4.8	290
1969	American Motors	Rebel	5.1	309
1969	American Motors	Rebel	5.6	343
1969	American Motors	Rebel	6.4	390
1969	Ford	Country Sedan	5.0	302
1969	Ford	Country Sedan	5.8	351
1969	Ford	Country Sedan	6.4	390
1969	Ford	Country Sedan	7.0	429
1969	Ford	Country Sedan	7.0	428
1969	Ford	Country Squire	5.0	302
1969	Ford	Country Squire	5.8	351
1969	Ford	Country Squire	6.4	390
1969	Ford	Country Squire	7.0	429
1969	Ford	Country Squire	7.0	428
1969	Ford	Custom	5.0	302
1969	Ford	Custom	5.8	351
1969	Ford	Custom	6.4	390
1969	Ford	Custom	7.0	429
1969	Ford	Custom	7.0	428
1969	Ford	Custom 500	5.0	302
1969	Ford	Custom 500	5.8	351
1969	Ford	Custom 500	6.4	390
1969	Ford	Custom 500	7.0	429
1969	Ford	Custom 500	7.0	428
1969	Ford	E-100 Econoline	5.0	302
1969	Ford	E-200 Econoline	5.0	302
1969	Ford	E-300 Econoline	5.0	302
1969	Ford	F-100	5.9	360
1969	Ford	F-100	6.4	390
1969	Ford	F-250	5.9	360

1969	Ford	F-250	6.4	390
1969	Ford	F-350	5.9	360
1969	Ford	F-350	6.4	390
1969	Ford	Fairlane	5.0	302
1969	Ford	Fairlane	5.8	351
1969	Ford	Fairlane	6.4	390
1969	Ford	Fairlane	7.0	428
1969	Ford	Fairlane	7.0	427
1969	Ford	Falcon	5.0	302
1969	Ford	Galaxie 500	5.0	302
1969	Ford	Galaxie 500	5.8	351
1969	Ford	Galaxie 500	6.4	390
1969	Ford	Galaxie 500	7.0	429
1969	Ford	Galaxie 500	7.0	428
1969	Ford	GT40	4.7	289
1969	Ford	LTD	5.0	302
1969	Ford	LTD	5.8	351
1969	Ford	LTD	6.4	390
1969	Ford	LTD	7.0	429
1969	Ford	LTD	7.0	428
1969	Ford	Mustang	5.0	302
1969	Ford	Mustang	5.8	351
1969	Ford	Mustang	6.4	390
1969	Ford	Mustang	7.0	429
1969	Ford	Mustang	7.0	428
1969	Ford	Ranch Wagon	5.0	302
1969	Ford	Ranch Wagon	5.8	351
1969	Ford	Ranch Wagon	6.4	390
1969	Ford	Ranch Wagon	7.0	429
1969	Ford	Ranch Wagon	7.0	428
1969	Ford	Ranchero	5.0	302
1969	Ford	Ranchero	5.8	351
1969	Ford	Ranchero	6.4	390
1969	Ford	Ranchero	7.0	428
1969	Ford	Thunderbird	7.0	429
1969	Ford	Thunderbird	7.0	428
1969	Ford	Torino	5.0	302
1969	Ford	Torino	5.8	351
1969	Ford	Torino	6.4	390
1969	Ford	Torino	7.0	428
1969	International	1000D	4.4	266
1969	International	1000D	5.0	304
1969	International	1100D	4.4	266
1969	International	1100D	5.0	304
1969	International	1200D	4.4	266
1969	International	1200D	5.0	304
1969	International	1300D	4.4	266

1969	International	1300D	5.0	304
1969	International	908C	5.0	304
1969	International	M1100	5.0	304
1969	International	M1200	5.0	304
1969	International	M1400	5.0	304
1969	International	M800	5.0	304
1969	International	M800 Navy	5.0	304
1969	International	M800 Post Office	5.0	304
1969	International	MA1200	5.0	304
1969	International	Scout	5.0	304
1969	Mercury	Colony Park	6.4	390
1969	Mercury	Colony Park	7.0	429
1969	Mercury	Colony Park	7.0	428
1969	Mercury	Comet	5.0	302
1969	Mercury	Comet	5.8	351
1969	Mercury	Comet	6.4	390
1969	Mercury	Cougar	5.0	302
1969	Mercury	Cougar	5.8	351
1969	Mercury	Cougar	6.4	390
1969	Mercury	Cougar	7.0	429
1969	Mercury	Cougar	7.0	428
1969	Mercury	Cyclone	5.0	302
1969	Mercury	Cyclone	5.8	351
1969	Mercury	Cyclone	6.4	390
1969	Mercury	Cyclone	7.0	429
1969	Mercury	Cyclone	7.0	428
1969	Mercury	Cyclone	7.0	427
1969	Mercury	Marauder	6.4	390
1969	Mercury	Marauder	7.0	429
1969	Mercury	Marauder	7.0	428
1969	Mercury	Marquis	6.4	390
1969	Mercury	Marquis	7.0	429
1969	Mercury	Marquis	7.0	428
1969	Mercury	Montego	5.0	302
1969	Mercury	Montego	5.8	351
1969	Mercury	Montego	6.4	390
1969	Mercury	Montego	7.0	428
1969	Mercury	Monterey	6.4	390
1969	Mercury	Monterey	7.0	429
1969	Mercury	Monterey	7.0	428
1970	American Motors	Ambassador	5.0	304
1970	American Motors	Ambassador	5.9	360
1970	American Motors	Ambassador	6.4	390
1970	American Motors	AMX	5.9	360
1970	American Motors	AMX	6.4	390
1970	American Motors	Hornet	5.0	304
1970	American Motors	Javelin	5.0	304

1970	American Motors	Javelin	5.9	360
1970	American Motors	Javelin	6.4	390
1970	American Motors	Rebel	5.0	304
1970	American Motors	Rebel	5.9	360
1970	American Motors	Rebel	6.4	390
1970	Ford	Bronco	5.0	302
1970	Ford	Country Sedan	5.8	351
1970	Ford	Country Sedan	6.4	390
1970	Ford	Country Sedan	7.0	429
1970	Ford	Country Sedan	7.0	428
1970	Ford	Country Squire	5.0	302
1970	Ford	Country Squire	5.8	351
1970	Ford	Country Squire	6.4	390
1970	Ford	Country Squire	7.0	429
1970	Ford	Country Squire	7.0	428
1970	Ford	Custom	5.0	302
1970	Ford	Custom	5.8	351
1970	Ford	Custom	6.4	390
1970	Ford	Custom	7.0	428
1970	Ford	Custom	7.0	429
1970	Ford	Custom 500	5.0	302
1970	Ford	Custom 500	5.8	351
1970	Ford	Custom 500	6.4	390
1970	Ford	Custom 500	7.0	429
1970	Ford	Custom 500	7.0	428
1970	Ford	E-100 Econoline	5.0	302
1970	Ford	E-200 Econoline	5.0	302
1970	Ford	E-300 Econoline	5.0	302
1970	Ford	F-100	5.0	302
1970	Ford	F-100	5.9	360
1970	Ford	F-100	6.4	390
1970	Ford	F-250	5.9	360
1970	Ford	F-250	6.4	390
1970	Ford	F-350	5.9	360
1970	Ford	F-350	6.4	390
1970	Ford	Fairlane	5.0	302
1970	Ford	Fairlane	5.8	351
1970	Ford	Fairlane	6.4	390
1970	Ford	Fairlane	7.0	429
1970	Ford	Falcon	5.0	302
1970	Ford	Falcon	5.8	351
1970	Ford	Falcon	7.0	429
1970	Ford	Galaxie 500	5.0	302
1970	Ford	Galaxie 500	5.8	351
1970	Ford	Galaxie 500	6.4	390
1970	Ford	Galaxie 500	7.0	429
1970	Ford	LTD	5.0	302

1970 Ford	LTD	5.8	351
1970 Ford	LTD	6.4	390
1970 Ford	LTD	7.0	429
1970 Ford	LTD	7.0	428
1970 Ford	Mustang	5.0	302
1970 Ford	Mustang	5.8	351
1970 Ford	Mustang	7.0	428
1970 Ford	Mustang	7.0	429
1970 Ford	Ranch Wagon	5.0	302
1970 Ford	Ranch Wagon	5.8	351
1970 Ford	Ranch Wagon	6.4	390
1970 Ford	Ranch Wagon	7.0	429
1970 Ford	Ranch Wagon	7.0	428
1970 Ford	Ranchero	5.0	302
1970 Ford	Ranchero	5.8	351
1970 Ford	Ranchero	7.0	429
1970 Ford	Thunderbird	7.0	429
1970 Ford	Torino	5.0	302
1970 Ford	Torino	5.8	351
1970 Ford	Torino	7.0	429
1970 International	1000D	4.4	266
1970 International	1000D	5.0	304
1970 International	1100D	4.4	266
1970 International	1100D	5.0	304
1970 International	1200D	4.4	266
1970 International	1200D	5.0	304
1970 International	1300D	4.4	266
1970 International	1300D	5.0	304
1970 International	M1100	5.0	304
1970 International	M1200	5.0	304
1970 International	M800	5.0	304
1970 International	M800 Post Office	5.0	304
1970 International	MA1200	5.0	304
1970 International	Scout	5.0	304
1970 Mercury	Colony Park	6.4	390
1970 Mercury	Colony Park	7.0	429
1970 Mercury	Colony Park	7.0	428
1970 Mercury	Cougar	5.8	351
1970 Mercury	Cougar	7.0	429
1970 Mercury	Cougar	7.0	428
1970 Mercury	Cyclone	5.0	302
1970 Mercury	Cyclone	5.8	351
1970 Mercury	Cyclone	7.0	429
1970 Mercury	Marauder	6.4	390
1970 Mercury	Marauder	7.0	429
1970 Mercury	Marauder	7.0	428
1970 Mercury	Marquis	6.4	390

1970	Mercury	Marquis	7.0	429
1970	Mercury	Marquis	7.0	428
1970	Mercury	Montego	5.0	302
1970	Mercury	Montego	5.8	351
1970	Mercury	Montego	7.0	429
1970	Mercury	Monterey	6.4	390
1970	Mercury	Monterey	7.0	429
1970	Mercury	Monterey	7.0	428
1971	American Motors	Ambassador	5.0	304
1971	American Motors	Ambassador	5.9	360
1971	American Motors	Hornet	5.0	304
1971	American Motors	Hornet	5.9	360
1971	American Motors	Javelin	5.0	304
1971	American Motors	Javelin	5.9	360
1971	American Motors	Matador	5.0	304
1971	American Motors	Matador	5.9	360
1971	Ford	Bronco	5.0	302
1971	Ford	Country Sedan	5.0	302
1971	Ford	Country Sedan	5.8	351
1971	Ford	Country Sedan	6.4	390
1971	Ford	Country Sedan	6.6	400
1971	Ford	Country Sedan	7.0	429
1971	Ford	Country Squire	5.0	302
1971	Ford	Country Squire	5.8	351
1971	Ford	Country Squire	6.4	390
1971	Ford	Country Squire	6.6	400
1971	Ford	Country Squire	7.0	429
1971	Ford	Custom	5.0	302
1971	Ford	Custom	5.8	351
1971	Ford	Custom	6.4	390
1971	Ford	Custom	6.6	400
1971	Ford	Custom	7.0	429
1971	Ford	Custom 500	5.0	302
1971	Ford	Custom 500	5.8	351
1971	Ford	Custom 500	6.4	390
1971	Ford	Custom 500	6.6	400
1971	Ford	Custom 500	7.0	429
1971	Ford	E-100 Econoline	5.0	302
1971	Ford	E-200 Econoline	5.0	302
1971	Ford	E-300 Econoline	5.0	302
1971	Ford	F-100	5.0	302
1971	Ford	F-100	5.9	360
1971	Ford	F-100	6.4	390
1971	Ford	F-250	5.9	360
1971	Ford	F-250	6.4	390
1971	Ford	F-350	5.9	360
1971	Ford	F-350	6.4	390

1971 Ford	Galaxie 500	5.0	302
1971 Ford	Galaxie 500	5.8	351
1971 Ford	Galaxie 500	6.4	390
1971 Ford	Galaxie 500	6.6	400
1971 Ford	Galaxie 500	7.0	429
1971 Ford	LTD	5.0	302
1971 Ford	LTD	5.8	351
1971 Ford	LTD	6.4	390
1971 Ford	LTD	6.6	400
1971 Ford	LTD	7.0	429
1971 Ford	M-400	6.4	390
1971 Ford	Maverick	5.0	302
1971 Ford	Mustang	5.0	302
1971 Ford	Mustang	5.8	351
1971 Ford	Mustang	7.0	429
1971 Ford	Ranch Wagon	5.0	302
1971 Ford	Ranch Wagon	5.8	351
1971 Ford	Ranch Wagon	6.4	390
1971 Ford	Ranch Wagon	6.6	400
1971 Ford	Ranch Wagon	7.0	429
1971 Ford	Ranchero	5.0	302
1971 Ford	Ranchero	5.8	351
1971 Ford	Ranchero	7.0	429
1971 Ford	Thunderbird	7.0	429
1971 Ford	Torino	5.0	302
1971 Ford	Torino	5.8	351
1971 Ford	Torino	7.0	429
1971 International	1010	5.7	345
1971 International	1110	5.7	345
1971 International	1210	5.7	345
1971 International	1310	5.0	304
1971 International	1310	5.7	345
1971 International	M1100	5.0	304
1971 International	M1200	5.0	304
1971 International	M800	5.0	304
1971 International	MA1200	5.0	304
1971 International	Scout II	5.0	304
1971 International	Scout II	5.6	345
1971 Mercury	Colony Park	5.8	351
1971 Mercury	Colony Park	6.6	400
1971 Mercury	Colony Park	7.0	429
1971 Mercury	Comet	5.0	302
1971 Mercury	Cougar	5.8	351
1971 Mercury	Cougar	7.0	429
1971 Mercury	Cyclone	5.8	351
1971 Mercury	Cyclone	7.0	429
1971 Mercury	Marquis	5.8	351

1971	Mercury	Marquis	6.6	400
1971	Mercury	Marquis	7.0	429
1971	Mercury	Montego	5.0	302
1971	Mercury	Montego	5.8	351
1971	Mercury	Montego	7.0	429
1971	Mercury	Monterey	5.8	351
1971	Mercury	Monterey	6.6	400
1971	Mercury	Monterey	7.0	429
1972	American Motors	Ambassador	5.0	304
1972	American Motors	Ambassador	5.9	360
1972	American Motors	Gremlin	5.0	304
1972	American Motors	Hornet	5.0	304
1972	American Motors	Hornet	5.9	360
1972	American Motors	Javelin	5.0	304
1972	American Motors	Javelin	5.9	360
1972	American Motors	Matador	5.0	304
1972	American Motors	Matador	5.9	360
1972	Ford	Bronco	5.0	302
1972	Ford	Country Sedan	5.0	302
1972	Ford	Country Sedan	5.8	351
1972	Ford	Country Sedan	6.6	400
1972	Ford	Country Sedan	7.0	429
1972	Ford	Country Squire	5.0	302
1972	Ford	Country Squire	5.8	351
1972	Ford	Country Squire	6.6	400
1972	Ford	Country Squire	7.0	429
1972	Ford	Custom	5.0	302
1972	Ford	Custom	5.8	351
1972	Ford	Custom	6.6	400
1972	Ford	Custom	7.0	429
1972	Ford	Custom 500	5.0	302
1972	Ford	Custom 500	5.8	351
1972	Ford	Custom 500	6.6	400
1972	Ford	Custom 500	7.0	429
1972	Ford	E-100 Econoline	5.0	302
1972	Ford	E-200 Econoline	5.0	302
1972	Ford	E-300 Econoline	5.0	302
1972	Ford	F-100	5.0	302
1972	Ford	F-100	5.9	360
1972	Ford	F-100	6.4	390
1972	Ford	F-250	5.0	302
1972	Ford	F-250	5.9	360
1972	Ford	F-250	6.4	390
1972	Ford	F-350	5.0	302
1972	Ford	F-350	5.9	360
1972	Ford	F-350	6.4	390
1972	Ford	Galaxie 500	5.0	302

1972 Ford	Galaxie 500	5.8	351
1972 Ford	Galaxie 500	6.6	400
1972 Ford	Galaxie 500	7.0	429
1972 Ford	Gran Torino	5.0	302
1972 Ford	Gran Torino	5.8	351
1972 Ford	Gran Torino	6.6	400
1972 Ford	Gran Torino	7.0	429
1972 Ford	LTD	5.0	302
1972 Ford	LTD	5.8	351
1972 Ford	LTD	6.6	400
1972 Ford	LTD	7.0	429
1972 Ford	Maverick	5.0	302
1972 Ford	Mustang	5.0	302
1972 Ford	Mustang	5.8	351
1972 Ford	P-350	5.0	302
1972 Ford	P-350	6.4	390
1972 Ford	Ranch Wagon	5.0	302
1972 Ford	Ranch Wagon	5.8	351
1972 Ford	Ranch Wagon	6.6	400
1972 Ford	Ranch Wagon	7.0	429
1972 Ford	Ranchero	5.0	302
1972 Ford	Ranchero	5.8	351
1972 Ford	Ranchero	7.0	429
1972 Ford	Thunderbird	6.6	400
1972 Ford	Thunderbird	7.0	429
1972 Ford	Torino	5.0	302
1972 Ford	Torino	5.8	351
1972 Ford	Torino	6.6	400
1972 Ford	Torino	7.0	429
1972 International	1010	5.0	304
1972 International	1010	5.7	345
1972 International	1110	5.0	304
1972 International	1110	5.7	345
1972 International	1210	5.0	304
1972 International	1210	5.7	345
1972 International	1310	5.0	304
1972 International	1310	5.7	345
1972 International	M1100	5.0	304
1972 International	M1200	5.0	304
1972 International	M800 Post Office	5.0	304
1972 International	MS1210	5.0	304
1972 International	Scout II	5.0	304
1972 International	Scout II	5.7	345
1972 Mercury	Colony Park	5.8	351
1972 Mercury	Colony Park	6.6	400
1972 Mercury	Colony Park	7.0	429
1972 Mercury	Comet	5.0	302

1972	Mercury	Cougar	5.8	351
1972	Mercury	Marquis	5.8	351
1972	Mercury	Marquis	6.6	400
1972	Mercury	Marquis	7.0	429
1972	Mercury	Montego	5.0	302
1972	Mercury	Montego	5.8	351
1972	Mercury	Montego	6.6	400
1972	Mercury	Montego	7.0	429
1972	Mercury	Monterey	5.8	351
1972	Mercury	Monterey	6.6	400
1972	Mercury	Monterey	7.0	429
1973	American Motors	Ambassador	5.0	304
1973	American Motors	Ambassador	5.9	360
1973	American Motors	Gremlin	5.0	304
1973	American Motors	Hornet	5.0	304
1973	American Motors	Hornet	5.9	360
1973	American Motors	Javelin	5.0	304
1973	American Motors	Javelin	5.9	360
1973	American Motors	Matador	5.0	304
1973	American Motors	Matador	5.9	360
1973	Ford	Bronco	5.0	302
1973	Ford	Country Sedan	5.8	351
1973	Ford	Country Sedan	6.6	400
1973	Ford	Country Sedan	7.0	429
1973	Ford	Country Squire	5.8	351
1973	Ford	Country Squire	6.6	400
1973	Ford	Country Squire	7.0	429
1973	Ford	Custom 500	5.8	351
1973	Ford	Custom 500	6.6	400
1973	Ford	Custom 500	7.0	429
1973	Ford	E-100 Econoline	5.0	302
1973	Ford	E-200 Econoline	5.0	302
1973	Ford	E-300 Econoline	5.0	302
1973	Ford	F-100	5.0	302
1973	Ford	F-100	5.9	360
1973	Ford	F-100	6.4	390
1973	Ford	F-250	5.0	302
1973	Ford	F-250	5.9	360
1973	Ford	F-250	6.4	390
1973	Ford	F-350	5.0	302
1973	Ford	F-350	5.9	360
1973	Ford	F-350	6.4	390
1973	Ford	Galaxie 500	5.8	351
1973	Ford	Galaxie 500	6.6	400
1973	Ford	Galaxie 500	7.0	429
1973	Ford	Gran Torino	5.0	302
1973	Ford	Gran Torino	5.8	351

1973	Ford	Gran Torino	6.6	400
1973	Ford	Gran Torino	7.0	429
1973	Ford	LTD	5.8	351
1973	Ford	LTD	6.6	400
1973	Ford	LTD	7.0	429
1973	Ford	M-400	5.9	360
1973	Ford	M-400	6.4	390
1973	Ford	Maverick	5.0	302
1973	Ford	Mustang	5.0	302
1973	Ford	Mustang	5.8	351
1973	Ford	P-350	5.9	360
1973	Ford	P-350	6.4	390
1973	Ford	Ranch Wagon	5.8	351
1973	Ford	Ranch Wagon	6.6	400
1973	Ford	Ranch Wagon	7.0	429
1973	Ford	Ranchero	5.0	302
1973	Ford	Ranchero	5.8	351
1973	Ford	Ranchero	7.0	429
1973	Ford	Thunderbird	7.0	429
1973	Ford	Torino	5.0	302
1973	Ford	Torino	5.8	351
1973	Ford	Torino	6.6	400
1973	Ford	Torino	7.0	429
1973	International	1010	5.0	304
1973	International	1110	5.0	304
1973	International	1210	5.0	304
1973	International	1310	5.0	304
1973	International	MS1210	5.0	304
1973	International	Scout II	5.0	304
1973	Mercury	Colony Park	5.8	351
1973	Mercury	Colony Park	6.6	400
1973	Mercury	Colony Park	7.0	429
1973	Mercury	Comet	5.0	302
1973	Mercury	Cougar	5.8	351
1973	Mercury	Cougar	6.6	400
1973	Mercury	Marquis	5.8	351
1973	Mercury	Marquis	6.6	400
1973	Mercury	Marquis	7.0	429
1973	Mercury	Montego	5.0	302
1973	Mercury	Montego	5.8	351
1973	Mercury	Montego	6.6	400
1973	Mercury	Montego	7.0	429
1973	Mercury	Monterey	5.8	351
1973	Mercury	Monterey	6.6	400
1973	Mercury	Monterey	7.0	429
1974	American Motors	Ambassador	5.0	304
1974	American Motors	Ambassador	5.9	360

1974	American Motors	Gremlin	5.0	304
1974	American Motors	Hornet	5.0	304
1974	American Motors	Hornet	5.9	360
1974	American Motors	Javelin	5.0	304
1974	American Motors	Javelin	5.9	360
1974	American Motors	Matador	5.0	304
1974	American Motors	Matador	5.9	360
1974	Ford	Bronco	5.0	302
1974	Ford	Country Sedan	5.8	351
1974	Ford	Country Sedan	6.6	400
1974	Ford	Country Squire	5.8	351
1974	Ford	Country Squire	6.6	400
1974	Ford	Custom 500	5.8	351
1974	Ford	Custom 500	6.6	400
1974	Ford	E-100 Econoline	5.0	302
1974	Ford	E-200 Econoline	5.0	302
1974	Ford	E-300 Econoline	5.0	302
1974	Ford	F-100	5.0	302
1974	Ford	F-100	5.9	360
1974	Ford	F-100	6.4	390
1974	Ford	F-250	5.0	302
1974	Ford	F-250	5.9	360
1974	Ford	F-250	6.4	390
1974	Ford	F-350	5.0	302
1974	Ford	F-350	5.9	360
1974	Ford	F-350	6.4	390
1974	Ford	Galaxie 500	5.8	351
1974	Ford	Galaxie 500	6.6	400
1974	Ford	Gran Torino	5.0	302
1974	Ford	Gran Torino	5.8	351
1974	Ford	Gran Torino	6.6	400
1974	Ford	LTD	5.8	351
1974	Ford	LTD	6.6	400
1974	Ford	M-450	5.9	360
1974	Ford	Maverick	5.0	302
1974	Ford	Ranch Wagon	5.8	351
1974	Ford	Ranch Wagon	6.6	400
1974	Ford	Ranchero	5.0	302
1974	Ford	Ranchero	5.8	351
1974	Ford	Torino	5.0	302
1974	Ford	Torino	5.8	351
1974	Ford	Torino	6.6	400
1974	International	100	5.0	304
1974	International	200	5.0	304
1974	International	MHC1310	5.0	304
1974	International	MS1210	5.0	304
1974	International	Scout II	5.0	304

1974	Mercury	Colony Park	6.6	400
1974	Mercury	Comet	5.0	302
1974	Mercury	Cougar	5.8	351
1974	Mercury	Cougar	6.6	400
1974	Mercury	Marquis	6.6	400
1974	Mercury	Montego	5.0	302
1974	Mercury	Montego	5.8	351
1974	Mercury	Montego	6.6	400
1974	Mercury	Monterey	6.6	400
1975	American Motors	Gremlin	5.0	304
1975	American Motors	Hornet	5.0	304
1975	American Motors	Matador	5.0	304
1975	American Motors	Matador	5.9	360
1975	Ford	Bronco	5.0	302
1975	Ford	Custom 500	5.8	351
1975	Ford	Custom 500	6.6	400
1975	Ford	E-100 Econoline	5.0	302
1975	Ford	E-100 Econoline	5.8	351
1975	Ford	E-100 Econoline Club Wagon	5.8	351
1975	Ford	E-150 Econoline	5.0	302
1975	Ford	E-150 Econoline	5.8	351
1975	Ford	E-150 Econoline Club Wagon	5.8	351
1975	Ford	E-250 Econoline	5.0	302
1975	Ford	E-250 Econoline	5.8	351
1975	Ford	E-250 Econoline Club Wagon	5.8	351
1975	Ford	E-350 Econoline	5.0	302
1975	Ford	E-350 Econoline	5.8	351
1975	Ford	Elite	5.8	351
1975	Ford	Elite	6.6	400
1975	Ford	F-100	5.0	302
1975	Ford	F-100	5.9	360
1975	Ford	F-100	6.4	390
1975	Ford	F-150	5.0	302
1975	Ford	F-150	5.9	360
1975	Ford	F-150	6.4	390
1975	Ford	F-250	5.0	302
1975	Ford	F-250	5.9	360
1975	Ford	F-250	6.4	390
1975	Ford	F-350	5.0	302
1975	Ford	F-350	5.9	360
1975	Ford	F-350	6.4	390
1975	Ford	F-500	5.4	330
1975	Ford	F-500	5.9	360
1975	Ford	F-500	6.4	390
1975	Ford	Gran Torino	5.8	351
1975	Ford	Gran Torino	6.6	400
1975	Ford	Granada	5.0	302

1975	Ford	Granada	5.8	351
1975	Ford	LTD	5.8	351
1975	Ford	LTD	6.6	400
1975	Ford	Maverick	5.0	302
1975	Ford	Mustang II	2.8	171
1975	Ford	Mustang II	5.0	302
1975	Ford	P-400	5.0	302
1975	Ford	Pinto	2.8	171
1975	Ford	Ranchero	5.8	351
1975	Ford	Torino	5.8	351
1975	Ford	Torino	6.6	400
1975	International	150	5.0	304
1975	International	200	5.0	304
1975	International	Scout II	5.0	304
1975	International	Travelall	5.0	304
1975	Mercury	Bobcat	2.8	171
1975	Mercury	Comet	5.0	302
1975	Mercury	Cougar	5.8	351
1975	Mercury	Cougar	6.6	400
1975	Mercury	Grand Marquis	6.6	400
1975	Mercury	Marquis	6.6	400
1975	Mercury	Monarch	5.0	302
1975	Mercury	Monarch	5.8	351
1975	Mercury	Montego	5.8	351
1975	Mercury	Montego	6.6	400
1976	American Motors	Gremlin	5.0	304
1976	American Motors	Hornet	5.0	304
1976	American Motors	Matador	5.0	304
1976	American Motors	Matador	5.9	360
1976	Ford	Bronco	5.0	302
1976	Ford	Custom 500	5.8	351
1976	Ford	Custom 500	6.6	400
1976	Ford	E-100 Econoline	5.8	351
1976	Ford	E-100 Econoline Club Wagon	5.8	351
1976	Ford	E-150 Econoline	5.8	351
1976	Ford	E-150 Econoline Club Wagon	5.8	351
1976	Ford	E-250 Econoline	5.8	351
1976	Ford	E-250 Econoline Club Wagon	5.8	351
1976	Ford	E-350 Econoline	5.8	351
1976	Ford	Elite	5.8	351
1976	Ford	Elite	6.6	400
1976	Ford	F-100	5.0	302
1976	Ford	F-100	5.9	360
1976	Ford	F-100	6.4	390
1976	Ford	F-150	5.0	302
1976	Ford	F-150	5.9	360
1976	Ford	F-150	6.4	390

1976 Ford	F-250	5.0	302
1976 Ford	F-250	5.9	360
1976 Ford	F-250	6.4	390
1976 Ford	F-350	5.0	302
1976 Ford	F-350	5.9	360
1976 Ford	F-350	6.4	390
1976 Ford	F-500	5.4	330
1976 Ford	F-500	5.9	360
1976 Ford	F-500	6.4	390
1976 Ford	Gran Torino	5.8	351
1976 Ford	Gran Torino	6.6	400
1976 Ford	Granada	5.0	302
1976 Ford	Granada	5.8	351
1976 Ford	LTD	5.8	351
1976 Ford	LTD	6.6	400
1976 Ford	Maverick	5.0	302
1976 Ford	Mustang II	2.8	171
1976 Ford	Mustang II	5.0	302
1976 Ford	P-350	5.0	302
1976 Ford	P-400	5.0	302
1976 Ford	P-500	5.0	302
1976 Ford	Pinto	2.8	171
1976 Ford	Ranchero	5.8	351
1976 Ford	Torino	5.8	351
1976 Ford	Torino	6.6	400
1976 International	Scout II	5.0	304
1976 Mercury	Bobcat	2.8	171
1976 Mercury	Capri	2.8	171
1976 Mercury	Comet	5.0	302
1976 Mercury	Cougar	5.8	351
1976 Mercury	Cougar	6.6	400
1976 Mercury	Grand Marquis	6.6	400
1976 Mercury	Marquis	6.6	400
1976 Mercury	Monarch	5.0	302
1976 Mercury	Monarch	5.8	351
1976 Mercury	Montego	5.8	351
1976 Mercury	Montego	6.6	400
1977 Ford	Bronco	5.0	302
1977 Ford	Custom 500	5.8	351
1977 Ford	Custom 500	6.6	400
1977 Ford	E-100 Econoline	5.8	351
1977 Ford	E-100 Econoline Club Wagon	5.8	351
1977 Ford	E-150 Econoline	5.8	351
1977 Ford	E-150 Econoline Club Wagon	5.8	351
1977 Ford	E-250 Econoline	5.8	351
1977 Ford	E-250 Econoline Club Wagon	5.8	351
1977 Ford	E-350 Econoline	5.8	351

1977 Ford	E-350 Econoline Club Wagon	5.8	351
1977 Ford	F-100	5.0	302
1977 Ford	F-100	5.8	351
1977 Ford	F-150	5.0	302
1977 Ford	F-150	5.8	351
1977 Ford	F-250	5.0	302
1977 Ford	F-250	5.8	351
1977 Ford	F-350	5.0	302
1977 Ford	F-350	5.8	351
1977 Ford	F-500	5.4	330
1977 Ford	F-500	5.9	360
1977 Ford	F-500	6.4	390
1977 Ford	Granada	5.0	302
1977 Ford	Granada	5.8	351
1977 Ford	LTD	5.0	302
1977 Ford	LTD	5.8	351
1977 Ford	LTD	6.6	400
1977 Ford	LTD II	5.0	302
1977 Ford	LTD II	5.8	351
1977 Ford	LTD II	6.6	400
1977 Ford	Maverick	5.0	302
1977 Ford	Mustang II	2.8	171
1977 Ford	Mustang II	5.0	302
1977 Ford	P-500	5.0	302
1977 Ford	Pinto	2.8	171
1977 Ford	Ranchero	5.0	302
1977 Ford	Ranchero	5.8	351
1977 Ford	Thunderbird	5.0	302
1977 Ford	Thunderbird	5.8	351
1977 Ford	Thunderbird	6.6	400
1977 International	Scout II	5.0	304
1977 Mercury	Bobcat	2.8	171
1977 Mercury	Capri	2.8	171
1977 Mercury	Comet	5.0	302
1977 Mercury	Cougar	5.0	302
1977 Mercury	Cougar	5.8	351
1977 Mercury	Cougar	6.6	400
1977 Mercury	Grand Marquis	6.6	400
1977 Mercury	Marquis	6.6	400
1977 Mercury	Monarch	5.0	302
1977 Mercury	Monarch	5.8	351
1978 Ford	Bronco	5.8	351
1978 Ford	E-100 Econoline	5.8	351
1978 Ford	E-100 Econoline Club Wagon	5.8	351
1978 Ford	E-150 Econoline	5.8	351
1978 Ford	E-150 Econoline Club Wagon	5.8	351
1978 Ford	E-250 Econoline	5.8	351

1978	Ford	E-250 Econoline Club Wagon	5.8	351
1978	Ford	E-350 Econoline	5.8	351
1978	Ford	E-350 Econoline Club Wagon	5.8	351
1978	Ford	F-100	5.0	302
1978	Ford	F-100	5.8	351
1978	Ford	F-150	5.0	302
1978	Ford	F-150	5.8	351
1978	Ford	F-250	5.0	302
1978	Ford	F-250	5.8	351
1978	Ford	F-350	5.0	302
1978	Ford	F-350	5.8	351
1978	Ford	Fairmont	5.0	302
1978	Ford	Granada	5.0	302
1978	Ford	LTD	5.0	302
1978	Ford	LTD	5.8	351
1978	Ford	LTD	6.6	400
1978	Ford	LTD II	5.0	302
1978	Ford	LTD II	5.8	351
1978	Ford	LTD II	6.6	400
1978	Ford	Mustang II	2.8	171
1978	Ford	Mustang II	5.0	302
1978	Ford	Pinto	2.8	171
1978	Ford	Ranchero	5.0	302
1978	Ford	Ranchero	5.8	351
1978	Ford	Thunderbird	5.0	302
1978	Ford	Thunderbird	5.8	351
1978	Ford	Thunderbird	6.6	400
1978	International	Scout II	5.0	304
1978	Mercury	Bobcat	2.8	171
1978	Mercury	Cougar	5.0	302
1978	Mercury	Cougar	5.8	351
1978	Mercury	Cougar	6.6	400
1978	Mercury	Grand Marquis	5.8	351
1978	Mercury	Grand Marquis	6.6	400
1978	Mercury	Marquis	5.8	351
1978	Mercury	Marquis	6.6	400
1978	Mercury	Monarch	5.0	302
1978	Mercury	Zephyr	5.0	302
1979	Ford	Bronco	5.8	351
1979	Ford	E-100 Econoline	5.0	302
1979	Ford	E-100 Econoline	5.8	351
1979	Ford	E-100 Econoline Club Wagon	5.0	302
1979	Ford	E-100 Econoline Club Wagon	5.8	351
1979	Ford	E-150 Econoline	5.0	302
1979	Ford	E-150 Econoline	5.8	351
1979	Ford	E-150 Econoline Club Wagon	5.0	302
1979	Ford	E-150 Econoline Club Wagon	5.8	351

1979	Ford	E-250 Econoline	5.0	302
1979	Ford	E-250 Econoline	5.8	351
1979	Ford	E-250 Econoline Club Wagon	5.0	302
1979	Ford	E-250 Econoline Club Wagon	5.8	351
1979	Ford	E-350 Econoline	5.0	302
1979	Ford	E-350 Econoline	5.8	351
1979	Ford	E-350 Econoline Club Wagon	5.0	302
1979	Ford	E-350 Econoline Club Wagon	5.8	351
1979	Ford	F-100	5.0	302
1979	Ford	F-100	5.8	351
1979	Ford	F-150	5.0	302
1979	Ford	F-150	5.8	351
1979	Ford	F-250	5.0	302
1979	Ford	F-250	5.8	351
1979	Ford	F-350	5.0	302
1979	Ford	F-350	5.8	351
1979	Ford	Fairmont	5.0	302
1979	Ford	Granada	5.0	302
1979	Ford	LTD	5.0	302
1979	Ford	LTD	5.8	351
1979	Ford	LTD II	5.0	302
1979	Ford	LTD II	5.8	351
1979	Ford	Mustang	2.8	171
1979	Ford	Mustang	5.0	302
1979	Ford	Pinto	2.8	171
1979	Ford	Ranchero	5.0	302
1979	Ford	Ranchero	5.8	351
1979	Ford	Thunderbird	5.0	302
1979	Ford	Thunderbird	5.8	351
1979	International	Scout II	5.0	304
1979	Mercury	Bobcat	2.8	171
1979	Mercury	Capri	2.8	171
1979	Mercury	Capri	5.0	302
1979	Mercury	Cougar	5.0	302
1979	Mercury	Cougar	5.8	351
1979	Mercury	Grand Marquis	5.0	302
1979	Mercury	Grand Marquis	5.8	351
1979	Mercury	Marquis	5.0	302
1979	Mercury	Marquis	5.8	351
1979	Mercury	Monarch	5.0	302
1979	Mercury	Zephyr	5.0	302
1980	Ford	Bronco	5.0	302
1980	Ford	Bronco	5.8	351
1980	Ford	E-100 Econoline	5.0	302
1980	Ford	E-100 Econoline	5.8	351
1980	Ford	E-100 Econoline Club Wagon	5.0	302
1980	Ford	E-100 Econoline Club Wagon	5.8	351

1980	Ford	E-150 Econoline	5.0	302
1980	Ford	E-150 Econoline	5.8	351
1980	Ford	E-150 Econoline Club Wagon	5.0	302
1980	Ford	E-150 Econoline Club Wagon	5.8	351
1980	Ford	E-250 Econoline	5.0	302
1980	Ford	E-250 Econoline	5.8	351
1980	Ford	E-250 Econoline Club Wagon	5.0	302
1980	Ford	E-250 Econoline Club Wagon	5.8	351
1980	Ford	E-350 Econoline	5.0	302
1980	Ford	E-350 Econoline	5.8	351
1980	Ford	E-350 Econoline Club Wagon	5.0	302
1980	Ford	E-350 Econoline Club Wagon	5.8	351
1980	Ford	F-100	5.0	302
1980	Ford	F-150	5.0	302
1980	Ford	F-150	5.8	351
1980	Ford	F-250	5.0	302
1980	Ford	F-250	5.8	351
1980	Ford	F-350	5.0	302
1980	Ford	F-350	5.8	351
1980	Ford	Granada	5.0	302
1980	Ford	LTD	5.0	302
1980	Ford	LTD	5.8	351
1980	Ford	Thunderbird	5.0	302
1980	International	Scout II	5.0	304
1980	Mercury	Cougar	5.0	302
1980	Mercury	Grand Marquis	5.0	302
1980	Mercury	Grand Marquis	5.8	351
1980	Mercury	Marquis	5.0	302
1980	Mercury	Marquis	5.8	351
1980	Mercury	Monarch	5.0	302