

ALIGN TO TRUNK  
LID SIDE EDGE

HOLE PUNCH \*  
DRILL TO  
7mm

ALIGN TO TRUNK LID REAR EDGE

- 1) CUT OUT TEMPLATE
- 2) ALIGN TEMPLATE
- 3) TAPE TEMPLATE
- 4) USE HOLE PUNCH TO TRUNK LID
- 5) DRILL HOLES TO LISTED SIZES USING A SERIES OF LARGER AND LARGER DRILL BITS
- 6) FLIP TEMPLATE OVER AND USE FOR OTHER SIDE OF TRUNK LID

HOLE PUNCH \*  
DRILL TO  
10mm